

Changing the battery of Shellman Grand Complication

Battery type : 280-44 (SR927W)

1. Open the back of the case. Please use an adequate tool to open it.
(Please refer to the picture we attached.)



2. Take out two screws. 1 and 2 in the picture. Then take off the plate that is on the movement. It is taken off easily.
3. Change the battery, 3 in the picture. Place the plate on the movement and screw 1 and 2 in the picture.
4. Snap the back of the case shut.
5. Always make sure to perform the All-Reset and Reference Position Setting procedures. Please refer to “4.Setting the Reference Position” in the manual.

※Caution

-There is a case that we cannot guarantee repair free service, when repair including changing battery is done by other than Shellman and our official distributors.

-Shellman including our official distributors changes the waterproof packing together with the battery. If not, there is a possibility that the function of water resistance is falling off. In this case we do not guarantee repair free service.

We don't recommend changing battery by your own.

When you change the battery, please understand above cautions and take full responsibility by your own. Sorry for your inconvenience but we cannot provide parts if you lose or break them.